

Season	Dates	Non-Ramp Hours	Ramp Hours	Effective MW Requirement
Winter	Dec 1 – Feb 29	HE1 – HE4, HE10 – HE16	HE5 – HE9, HE17 – HE24	Non-Ramp = 525MW Ramp = 800MW
Spring	Mar 1 – May 31	HE1 – HE5, HE9 – HE17	HE6 – HE8, HE18 – HE24	Non-Ramp = 525MW Ramp = 800MW
Summer	Jun 1 – Aug 31	HE1 – HE5, HE15 – HE18	HE6 – HE14, HE19 – HE24	Non-Ramp = 525MW Ramp = 800MW
Fall	Sep 1 – Nov 30	HE1 – HE5, HE9 – HE17	HE6 – HE8, HE18 – HE24	Non-Ramp = 525MW Ramp = 800MW

If you have any questions, please call PJM Customer Service on (866) 400-8980 or send email to custsvc@pjm.com